



www.dieselboss.com

VuQube no-drill installation procedure.

*** This instruction pertains ONLY to the no-drill VuQube bracket as sold by Dieselboss, Inc. This is NOT intended for any other bracket or mount. ***

1. Clean flat area surface where the bracket is to be mounted with Acetone. Make sure surface is free from foreign material and the paint is tight. The vertical surface where you are mounting the bracket CANNOT have any texture or "ribs."
2. Measure the total height of the truck from the ground. (Do Not Exceed over 13' 6" to the top of the cube.) If possible, place only 4" of the cube higher than the cab of vehicle.
3. For tall vehicles that the cube cannot be placed 4" higher than the cab, place the cube even with the top of the cab. This will require the driver to NOT Park with the front of the vehicle pointing SOUTH. Satellites are always in the southern sky. The cube receiver will have to be pointing in the southern sky at the proper angle to receive satellite signal. (Booklet and instructions enclosed with package.)
4. Warm area where bracket is to be installed to about 100 degrees. This can be done with a heat gun or propane torch.
5. Remove the clear backing tape from the back of bracket.
6. Firmly press the bracket to the flat surface.
7. Heat the vertical area of the bracket to about 100 degrees again. You should be able to press with your hand firmly making sure the bracket is in full contact with flat surface. Repeat this warming and pressing action a minimum of 3 times.
8. Apply a bead of silicone sealer on all 4 sides of the bracket where it meets against your vehicle to block any water from truck-washes and hoses.
9. Bolt on the horizontal part of the bracket to the vertical installed section now using the bolts provided and tighten them securely.
10. Install the VuQube on top of the bracket and secure with the bolts provided.

*** Dieselboss Inc. will not be held liable for the installation of the no-drill mounts by any third party, and these instructions must be followed to ensure maximum adhesion of the no-drill bracket. ***

Questions: call Dieselboss Inc. at 866-851-2346