

## Item Number \_\_\_\_\_

RAM-VB-136 & RAM-VB-136-SW1

# RAM No-Drill™ Seat Bases

National Products, Inc.

## Vehicle base for the CHEVROLET ASTRO VAN (2000-2011)

### SPECIFICATIONS

#### Placement

Attaches between seat frame and floor board. Uses front and rear, inside seat studs.

#### Drilling Required

No - uses existing seat bolts

#### Seat Configuration

Bucket

#### Construction/Finish

Steel/Black Powdercoat

#### Pole or Pedestal

Included on Base

#### Weight

6.1 lbs.

#### Dimensions

A = 14.57", B = 7.25", C = 17.75"

Hole Center = 12.625"

### Features

---

Installs in minutes with no drilling required

### Misc.

---

Rock solid construction

Lifetime warranty

---

National Products, Inc.

Phone: 206-763-8361

Fax: 206-763-9615

Address: 1205 S Orr St

Seattle, WA 98108

Website: [www.ram-mount.com](http://www.ram-mount.com)

Email: [staff@ram-mount.com](mailto:staff@ram-mount.com)



RAM-VB-136-SW1



RAM-VB-136



**Item Number** \_\_\_\_\_

RAM-VB-136 &amp; RAM-VB-136-SW1

**RAM No-Drill™ Seat Bases**

National Products, Inc.

**Vehicle base for the  
CHEVROLET ASTRO VAN (2000-2011)****INSTALLATION INSTRUCTIONS**

1. Loosen the front door side and rear door side nuts holding the passenger side seat to the floor board.
2. Remove the front drivers side and rear drivers side nuts holding the passenger seat to the floor board.
3. Prior to lifting the drivers side of the passenger seat upward, note the placement of the seat belt anchor. This is sometimes located at the inner rear seat frame where it uses the seat stud to hold it in place. If this is the case for your vehicle, be sure to reposition the seat belt anchor as was done by the factory.
4. Lift the drivers side of the passenger seat upward enough to clear the seat frame studs projecting upward from the floor board.
5. Place the No-Drill™ base in between the seat frame and seat studs and align the holes in the base with those of the base.
6. Once aligned, lower the seat frame back into place, check placement of seat belt anchor, and re-install and fully tighten all four of the nuts securing the seat to the floor board.

National Products, Inc.  
Phone: 206-763-8361  
Fax: 206-763-9615  
Address: 1205 S Orr St  
Seattle, WA 98108  
Website: [www.ram-mount.com](http://www.ram-mount.com)  
Email: [staff@ram-mount.com](mailto:staff@ram-mount.com)

